


# INSTALLATION DIGITAL BOARD FOR IN200 & PR300 Signature

**Before any operation, switch off your appliance.**


Get off screws of rear plate (3 screw)



Place the plastic button (hiding the Bluetooth antenna) and fix the board on the chassis.



Connect the flat cable on the main board connector



In case of IN50, 80, 100 and PR200 signature it is necessary to wait 5 seconds of initialization before being able to exit standby at the first power on.

**The digital board includes:**

- **1 Bluetooth receiver**
- **2 Coaxial inputs** (24Bits/192kHz)
- **2 Optical inputs** (24Bits/192kHz)
- **1 USB-B input:** PCM (16 bits to 32bits up to 384 kHz) & DSD (64 & 128)

**USB DRIVER:** To use the USB-B asynchronous input, you need to download a driver on your computer using Windows software.

<https://www.atoll-electronique.com/en/presse-support-2/>